



EA24 PERFUME DISPENSER




● TECHNO PARAMETER

RATED VOLT	DC3V
STATIC CURRENT	50uA
RETED CURRENT	500mA
POWER	1.5W

● INSTALLATION SHOW



● FUNTION INSTRUCTION



● SPECIFICATION

OUTER SIZE	L86*W83*H238MM
WEIGHT	400g
MATERIAL	ABS
BATTERY	2pcs "D"

● MOUNTING THE DISPENSER

For best operation, mount the unit 7-9 feet above the floor.

1. Place the Dispenser in the location to be mounted, make a mark on the wall surface through the 2 mounting holes.
2. Drill the holes at the marks and insert the anchors.
3. Place the unit on the wall and affix the screws.
4. Ensure the dispenser is mounted securely on the wall.

● OPERATING THE DISPENSER

1. Insert 2 "D" **ALKALINE batteries** in the battery compartment.

2. Select the **Spray Interval** switch to the preferred setting:5,15 and 25 minutes.
3. Select the **Operation Mode** switch to preferred setting:24 hours operations or Day Mode, or 24 hours operations.
 - When 24H is selected-units operates at selected spray interval for 24 hours.
 - When Day is selected-unit operates at selected spray interval in lighted conditions only.
4. Before inserting the can, push the hammer to the "UP" position.
5. Insert aerosol refill can in between the metal bracket in the dispenser. Make sure the actuator points towards the front of the dispenser.
6. Using the **On/Off Switch**, turn the unit on. The green LED will light up for 2 seconds.
7. Test spray by pressing **Test Switch**. Always ensure that the dispenser is turned away from your face when testing the spray.
8. When battery is low, Green LED will does not blinking

Factory Setting is 25 minute spray interval with 24 hours operations.

● PRECAUTIONS

1. This dispenser does not have waterproof function, please place dispenser away from dampness.
2. Place dispenser away from food preparation areas.
3. Avoid spraying onto plastic, varnished or painted surfaces.
4. Always replace with new alkaline batteries and never leave dead batteries in the unit.
5. If you do not use dispenser on long time, please take out batteries and refill can.

EURONICS